firewood carrier

just ask Jo-ann how to

more projects, tips & techniques at Joann.com™

Project courtesy of Io-Ann Fabric and Craft Stores



SUPPLIES & TOOLS:

- 1½ yds Canvas or heavyweight fabric
- 2 Wood dowel rods
- Iron-on letters
- Basic sewing supplies
- Iron
- Sewing machine
- Hand saw

DIRECTIONS:

- 1. Fold fabric in half with right sides together to form a rectangle that measures 22"-24" by 48".
- 2. To create handle, on short end, measure in 9" on both sides and mark.
- 3. Measure down 6" from the marks and draw a line from mark down and across.
- 4. Cut fabric along the lines, rounding corners forming a U-shaped cut.
- 5. Sew a 1/2" seam all around carrier leaving an opening for turning.
- 6. Trim corners, turn to right side; press.
- 7. Top stitch 1/4" in from edges.
- 8. Measure in 3½" from each short side, fold ends to marks and sew to form casing for dowels on both sides.
- 9. Follow manufacturer's directions to iron letters onto side of carrier.
- 10. Cut lengths of wood dowels to fit pockets; insert into pockets.

Skill Level 2: Some sewing experience needed

Approximate Crafting Time: 2 hours



