

**Victorian Night Light Lampshade**

Courtesy of Singer Company LTD®



**Supplies:**

- Cream silk dupioni cut 9" x 12"
- Iron-on stabilizer (med. wt.) cut 9" x 12"
- Robison Anton rayon thread
  - Color: Green #2545
  - Pink #2248
- Madeira Décor No. 6
  - Green #1503
- Liquid seam sealant
- Wash-away pen
- Chromium needles size 80
- Wing needle
- Open-toe appliqué foot
- Cording foot
- Adjustable blind hem foot
- Beaded trim 12"
- Velcro 5" (self adhesive)
- Clear plastic cup (9 oz. or bigger)
- Pressing cloth

**Directions:** (Project for Quantum® 9940)

**Fabric Preparation and Set-Up**

1. Press the iron-on stabilizer to the wrong side of silk.
2. Cut fabric to the size of a standard piece of copy paper (8½" x 11").
3. Import picture file of angels to a blank page in a word document. Carefully hand feed stabilized fabric through copier and print. Allow the ink to dry thoroughly on fabric. Use a pressing cloth over the inked fabric and press with a dry iron to set ink.



- Place template pattern for shade on fabric and cut out. Do not remove the stabilizer.
- Find the center of the shade vertically. Find the center of each half. Draw a line vertically on the center of each half. (*See Shade Template*)

#### Directions

- Thread needle and bobbin with green rayon thread. Attach the Cording foot and feed two threads of Décor through center guide.
- Select zig-zag stitch #8 and adjust the settings: change the width to (2.0) and the length to (0.5).
- Stitch down the cording line drawn on shade fabric. (*See Figure 1*)



- Change the top thread to pink and select stitch #81. Set the stitch width at 6.0
- Change the foot to the Blind hem foot. Move the white guide of the foot all the way to the left. Sew down the right side of the green corded stitching from the top to bottom of the shade. When sewing, guide the white ridge of the foot along the green stitched line. (*See Figure 2*)



- Before stitching the other side, engage the *mirror button* to flip design. Sew from the bottom of the shade to the top of the shade on the opposite side.
- Select stitch #25 and insert wing needle into the machine. Adjust the stitch width to (4.0) and change foot to the Open-toe foot. Stitch around the green line on the heart surrounding the angels' faces.
- Remove pink thread and wing needle from machine. Change the foot back to the Cording foot. Set the zig-zag stitch #8 to a width of (2.0) and length of (0.5). Stitch down, forming the corded edge on the side of decorative stitch #81. Be careful to align the corded edge close to the pink stitching. (*See Figure 3*)



- Change foot to the Open-toe foot. Select stitch #26 Scallop. Sew across the bottom of the shade, guiding the right side of the foot along bottom edge of the shade. (*See Figure 4*)



- Set machine for zig-zag stitch #8. Adjust settings to a width of (3.0) and a length of (0.5).

11. Carefully stitch over previous line of Scallop stitching to form a Satin scallop. (*See Figure 5*)



12. Trim close to stitched scallop with appliqué scissors. (*See Figure 5.1*)



13. Change the presser foot back to the Cording foot. Feed two cords through the center of guide. Stitch along scallops guiding the cord on the edge of the scallop, forming a raised and finished edge. (*See Figure 6*)



14. Continue to finish the other three unfinished edges around the shade with the corded finish. Apply liquid seam sealant to all corners to prevent fraying. (*See Figure 7*)



15. Hot glue beaded fringe to back side of shade. Anchor the edges of the fringe to prevent beads from coming unstrung.



16. Remove plastic from cup using template as a guide. Personalize the cut out of the cup to fit the shade. Attach Velcro strips on each side of cup. Attach a piece of Velcro along the top to adhere cup to the light cover. (*See Picture 8*)

**17. Start dreaming up the next holiday lampshade!**



*Singer® and Quantum® are registered trademarks of the Singer Company Ltd.*

**Skill Level: Some experience helpful**

Due to seasonal nature of project, supplies are available for a limited time only. Please read all instructions prior to beginning; read and follow all manufacturers' instructions for all tools and materials used. Provide adult supervision if children participate in this and all craft projects. Because Jo-Ann Stores, Inc. has no control over the use of materials and tools, nor surroundings, during construction of projects, Jo-Ann Stores, Inc. disclaims any liability for injury, damage or other untoward results. Content of this project sheet is presented in good faith, but no warranty is given, nor results guaranteed. ©2006 Jo-Ann Stores, Inc. All rights reserved. 197-386

**JO-ANN**  
fabric and craft stores

